

## **Veloce Spares Ltd**

### **TYPES OF TRANSFER**

#### **Duplex in Reverse (Varnish Fixing)**

On inspection, these look like a mirror image  
Instructions for using Real Paint Transfers

Apply a thin and evenly distributed coat of varnish or pale gold size to the transfer (confine it to just over area of design or letters) and leave until tacky.

Loosen corner of the DUPLEX paper to facilitate removal later, then apply transfer in correct position.

Press down firmly over the entire surface with a roller or squeegee, working from the centre outwards to avoid air bubbles.

Now remove backing paper with care, leaving tissue still on site. Smooth out again where necessary, removing all air bubbles. Persistent bubbles must be punctured.

Leave to dry for at least an hour, then moisten the tissue support and peel it off. Now wipe over the entire surface with a paraffin moistened cloth to remove surplus varnish or gold size.

To give extra protection, the entire design may then be varnished over if desired

#### **Water-Slide**

On inspection, these look normal  
Instructions for using water-slide transfers.

Float the transfer face up with its backing paper on the surface of the water until the backing paper appears soaked through and the transfer can just be gently nudged around on it.

Slide into place, then press gently with pieces of good quality white paper until flat, and no longer wet. Leave to dry.

#### **Stick on (rarely used)**

Have a clearly self-adhesive surface.